



Control and monitoring functions LF24-SR

BELIMO®

Remote control 0...100%




Minimum position




w016712


Override control



Control by 4...20 mA via external resistor



Position indication and / or master-slave control (depending on position)



Function monitoring

